



# T-Trainer Replacement Bed

## Installation Instructions



Skip Holes HERE



1. Start springing the bed from the front of the T-Trainer. The first springs will be difficult to attach (we recommend using gloves and an allen wrench to pull and place the springs into each hole- see diagram C).
2. Attach 4 springs on each side, then skip a hole, ensuring you skip the same hole on each side of the frame.
3. Attach 2 more springs, skip a hole, attach 5 springs, and skip a hole again.
4. Attach springs to all remaining holes, skipping your last set of holes that are located the 4th hole from the back.

### KEY POINTS:

- Skips occur mainly around the bends in the frame and once in the middle to keep the bed straight and tight.
- Never skip any D-rings on the bed, only holes on the frame.
- No D-ring should have more than one spring.

Any questions or problems, please call  
Tumbl Trak at (800) 331-4362



**Tumbl Trak**  
Train Smart